

Rev 5 PCB QMX Schematics


Note, component numbering indicates the page number of the schematics; e.g. all components numbered 1xx are on page 1 etc. R106, for example, is on schematics page 1.




1: Power supplies




2: Microcontroller and digital sections



3: LCD and Controls boards



4: Receiver



5: Transmitter